



+ [View More](#)

Product Family

SmartFit Multiple-Use Earplug

Delivers superior comfort and a truly personalized fit

[Learn more about our products at howardleight.com](http://howardleight.com) >

[Learn more about hearing conservation at hearforever.org](http://hearforever.org) >



Product Numbers & Ordering Information

	Product Numbers	Details
	SMF-30	SmartFit NRR 25 Canada Class A(L)

Overview

Key Features

- Patented Conforming Material Technology uses body heat to adapt to the individual shape of each wearer's ear canal
- Delivers superior comfort and a truly individual fit
- Simplifies inventory control – a single product fits almost every wearer
- Detachable cord system and HearPack storage case

Recommended Industries/Use

- Agriculture

SmartFit Multiple-Use Earplug

- Chemical
- Construction
- Fire Protection
- Forestry
- Government
- Law Enforcement
- Manufacturing
- Medical
- Military
- Mining
- Municipal Services
- Oil and Gas
- Pharmaceutical
- Steel and Metals
- Transportation
- Utilities
- Welding
- Wind Energy

Hazards

- Noise

Regulations

- 29 CFR 1910.95 - OSHA Occupational Noise Exposure (US)
- ANSI S3.19-1974 - Attenuation Test Protocol (US)
- Part II, (R.S.C. 1985, c. L-2) - Canada Labour Code
- Z94.2-1994 - Attenuation Test Protocol (CAN)
- 2003/10/EC - EU Hearing Directive
- 89/686/EEC - EU Directive/PPE
- Category II - EC Category/PPE
- EN 352-2:2002 - EU Standards
- NOHSC: 1007 (2000) - National Standard for Occupational Noise (AUS/NZ)
- NR 15 - Security and Health of Work, Annexes 1 and 2, n°3.214/1978 - Occupational Noise Regulations (BR)
- ANSI S12.6/1997 - Method B - Attenuation Test Protocol (BR)

Historical Brand

Howard Leight

Specifications

Color	Orange
Shape	3 Flange
Material	TPE
Packaging Options	HearPack

SmartFit Multiple-Use Earplug

Cord Options	Detachable Nylon Cord
NRR	25
Canada Class	A(L)
SNR	30
SLC80	20 dB / Class 3

EU Certifications

- European Directives – 89/686/EEC
- EC Category PPE – Category II
- Standards – EN 352-2:2002
- EC Certification Number – 1134
- EC Attestation Number – 030649; 040809 & 040950
- Laboratory – INSPEC

AUS Certifications

- Standardsmark License #1133/1

Literature & Documents

Data Sheet Smartfit Earplug SMF-30A, SMF-30W-PA - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protec

<12\$%EktCertification12\$%> False ► ► ► SMARTFIT™ MULTIPLE USE EARPLUG

PRODUCT INFORMATION Ears are like people, each one is unique and different. That is what makes SmartFit such a marvel of user-friendly design. SmartFit is the only multiple-use earplug with Conforming Material Technology™ providing the ultimate cust

Earplug Instruction Poster - EN

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protec

Earplug Instruction Poster - ES

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protec

Earplug Instruction Poster - FR

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protec

1. While holding the stem, reach a hand over your head and gently pull top of your ear up and back.

SmartFit Multiple-Use Earplug

Training & Proper Use

2. Insert the earplug so all flanges are well inside your ear canal.
3. If properly fitted, the tip of the earplug stem may be visible to someone looking at you from the front.
4. Proper Fit – If either or both earplugs do not seem to be fitted properly, remove the earplug and reinsert.
5. Removal – Gently twist earplug while slowly pulling in an outward motion for removal.
6. Acoustical Check – In a noisy environment, with earplugs inserted, cup your hands over your ears and release. Earplugs should block enough noise so that covering your ears with your hands should not result in a significant noise difference.

Additional Information

CARE + MAINTENANCE

- INSPECT – Prior to fitting, examine your earplugs for dirt, damage, deformation or extreme hardness—discard immediately if compromised.
- CLEAN – Wash Multiple-Use earplugs with mild soap and warm water only. Pat dry with a towel and store in a case when not in use. Do not treat with any other substances, as the earplugs may degrade and compromise use.
- HYGIENE – With proper maintenance, Multiple-Use earplugs can last for 2-4 weeks.

RELATED PRODUCTS

© Honeywell International Inc.



SUCCESS UDYOG PVT. LTD.

Registered Office: Office No. 315/316, 3rd floor, City Space, Sr.No.198/1A,
Pune Nagar Road, Pune 411014, Maharashtra

Godown : Jadhav warehousing, Gat no. 1338/1, Priyankanagari, Wagholi, Pune – 411207
Off. Tel: 020-40188288/216/244/221-228, **Cell-**9371919702/9370223873 **Fax:** 020-40188227/299
Email: sales@successudyog.com **Web:** www.successudyog.com